



PRODUCTS

- 60 lb (27.2 kg) 3-1 Sand/Cement - Burlap (Product No. NR 83999)
- 60 lb (27.2 kg) Pure Sand - Burlap (Product No. NR 83997)
- 60 lb (27.2 kg) Revetment - RipRap Burlap (Product No. NR 83994)

SLINGBAG™ COVERAGE

Estimated Size of Bag Filled:	3.75 in x 16 in x 23 in / (95.25 mm x 405 mm x 584 mm)
Estimated Size of Burlap Pallet Filled:	45 in x 48 in x 36 in / (1.1 m x 1.2 m x 0.9 m)
1 Burlap Bag	Approximately 0.8 cu ft (22.65 L)
1 sq yd (.84 m²)	Approximately 5 Burlap Bags
1 cu yd (.76 m³)	Approximately 34 Burlap Bags
1 Pallet of Burlaps	Approximately 1.65 cu yd (1261.5 L)



Contact:
Tim Grazier
tgrazier@quikrete.com
(601) 798-6021

www.slingbag.net



**THE NEW STANDARD
IN REVETMENT &
EROSION CONTROL**



- SLOPE PROTECTION
- DAMS
- BULKHEADS
- CULVERTS
- EMBANKMENTS



The SlingBag™ patented system is designed to efficiently and safely store, move and place biodegradable burlap bags five times faster and safer than conventional methods – EVERY TIME!

SlingBag™ Applications:

- Slopes & Embankments
- Bulkheads
- River Banks
- Canals
- Culverts
- Spillways
- Dams
- Beaches
- Lake Fronts

SlingBag™ Benefits:

- Interlocking, running-bond retaining walls
- Erosion control for shorelines, culverts and ditches
- Fill large voids or depressions in lake & river bed floors
- Slope stabilization



SlingBag™ Features:

- Woven polypropylene fabric SlingBag™ with four 24 inch (0.6 mm) polyester lifting loops. Holds fifty six 60 lb (27.2 kg) burlap bags.
- SlingBag™ can be lifted with a single point pick-up and be lowered onto a land job site.
- The burlap bags can be released and placed by simply unhooking any two lifting loops in a row and lifting the SlingBag™.



Limitations:

The SlingBag™ system is not intended for un-reinforced vertical walls higher than 2 feet (0.6 m), vertical walls can be extended to 10 feet (3 m) and higher with proper engineering design. Installations over 2 feet typically require metal stakes to secure the first layer to the ground, metal staples and horizontal metal ties into the vertical soil mass.



Slope & Embankment Erosion Control:

When using the SlingBag™ system on a slope, bags should be placed in a stair-step fashion, setting back succeeding rows to the full height of the slope at a minimum of 45° from vertical. Place bags in a running bond pattern with ends butted together and corners interlocking. Anchor each bag to the slope with 3/8 inch (9.5 mm) rebar and back fill dirt to assure a solid bank. The use of geotextile fabric will improve the stability of the installation.

